



INSTANT SUN SHELTER



OPENING THE SUN SHELTER

1. Remove the sun shelter from its bag. Spread the floor of the sun shelter evenly on the ground. See figure 1.
 2. Click the four legs into the straight, locked position and hold the two pieces of cord over the center hub of the structure. See figure 2.
 3. Still holding the cords, use your free hand to give the sun shelter a shake, loosening and fanning out the structure. Hold and steady the center hub pulling the two cords simultaneously with your other hand in an upward direction. The lower half of the hub will be pulled up to join the top half. See figure 3.
- NOTE:** Do not force this stage of assembly, as it may damage the opening mechanism. If the sun shelter is resistant to opening, simply lower the mechanism, gently shake and try again.
4. The sun shelter is now erect and ready to use. To keep the sun shelter secure in strong wind, fill the attached pockets with sand. You may also use plastic stakes if necessary.

WARNING: DO NOT USE IN STRONG WINDS. THIS PRODUCT IS NOT A WIND SHELTER.



FIGURE 1



FIGURE 2



FIGURE 3

COLLAPSING THE SUN SHELTER

1. Remove stakes and empty any sand from sand pockets. Remove any belongings.
2. Place your hands on either side of the lower hub poles and gently push down until the hub collapses into the vertical position. See figure 4.
3. Very gently roll the fabric around the collapsed structure, pushing air out as you do. Pack the sun shelter into its bag.



FIGURE 4

CARE

To clean: Brush off excess sand, hose down with fresh water or wipe with a wet sponge. Do not use detergent. Air dry.

General care: To preserve the life of the opening mechanism, remember to never force parts during assembly. If resistance is experienced, release, shake and start over.